



# INSTALLATION STEPS

## SINGLE GTP


1



2




3




MAKE SURE ALL 4 BOLT IS SCREW INTO PLACE BEFORE PROCEED TO STEP 5

4



A (1:1)



**TO NOTE:**

TO OPEN, PRESS DOWN LIGHTLY ON THE 4 BUCKLE HEAD,  
AND PUSH OUT THE FRONT PANEL